## **POLMAR DB-50M**

## How to expand the frequency bands:

- Hold "SQL" key and switch on at the same time (on the right side, the display shows
  - "MODE 02");
- With the left side channel knob set "MODE 01";
- Switch the transceiver off and then on again.

## **Transponder function:**

- Switch on the function at menu n. 12 (X-RPT).